

FLEETWOOD FOLDING TRAILERS, INC.
INSTALLATION INSTRUCTIONS

1968B565

July 2006

PART NUMBER: 4755A7801 UNIVERSAL AUTO CHANGEOVER KIT

These Installation Instructions are intended for 2005 to present Highlander Series trailers with the elevated gas bottle mounting tray, 2005 to present Scorpion, and 2006 to present Evolution.

IMPORTANT NOTICE

These instructions are for the use of qualified individuals specifically trained and experienced in the installation of this type equipment and related system components. Installation and service personnel are required by some states to be licensed. Persons not qualified shall not attempt to install this equipment nor interpret these instructions.

INSTALLATION INSTRUCTIONS

1. Remove the ½” copper gas line from the current gas regulator assembly that is mounted on the front of the elevated mounting tray. Disconnect the gas hoses from each gas bottle.
2. Remove the large wing nut and hold down bracket from the threaded gas bottle mounting rod. Remove the existing regulator assembly from the trailer.
3. Hold the regulator assembly with the change-over regulator on top and facing towards the coupler. Slide the bottom hole of the regulator assembly “C” bracket slightly over the top of the threaded bolt. Next, slide the gas bottle hold-down bracket over the threaded bolt with the teeth facing downward. Then slide the top hole of the regulator assembly “C” bracket over the top of the threaded bolt. Finally, place the large wing nut over the threaded bolt and tighten down using the lock nut.

NOTE: Prior to attaching gas hoses to the changeover regulator assembly, apply pipe thread sealant with Teflon to the fittings.

4. Attach the black gas hose from the bottom of the regulator to the ½” copper gas line from the trailer.
5. Attach the two 12” black side gas hoses to the corresponding gas bottle.
6. Perform a leak test to the LP gas system.